PalCare®

Your PalCare Server

Step 1: Remove the white PalCare Server from this box.

Step 2: Mount the white PalCare Server next to the existing blue PalCare Server on the wall with the included screws.

Step 3: Plug the included orange network cable into the white PalCare Server.

Step 4: Route the orange network cable through your networking closet and plug it into an open port on your network switch. It's best to plug this cable into the same switch as the existing blue PalCare Server

Step 5: Plug the power adapter into the white PalCare Server.

Step 6: Plug the power adapter into a free 'Surge+Battery' outlet on the black PalCare battery backup unit.

Step 7: Wait about 60 seconds, or until the small screen on the white PalCare Server lights up with information.

Step 8: Send an email to support@palcare.com with your community name so we can verify connectivity Thank you for your assistance.

Specifications:

- DC Input Voltage: 12 VDC @ 2000mA
- LED's: link, speed/data, power
- Operating Temperature: 0° - 70° C
- Dimensions: 15.9cm x 10.6cm x 4cm
- 10/100 RJ45 Ethernet connection*

* Requires high speed internet connection

Features:

- Eliminates the need for a PC based nurse call system
- Small footprint form factor
- Ultra low power consumption
- Industrial grade components
- Robust processing power
- Capable of desk or wall mounting

PalCare®

309 N Water St #425
Milwaukee, WI 53202
www.palcare.com

(920) 694-0085
sales@palcare.com